

AREA DRAIN AND BASEMENT ENTRY DRAIN PROCEDURES

1. Obtain homeowners permission or leave explanatory door hanger.
2. Assemble appropriate dispensing equipment.
3. Fill small plastic container with pre-mixed dye (some dye colors stain, use caution and care when near any private property).
4. Follow operations manual procedures for trailer start up and operation.
5. Assemble proper water dispensing equipment and dispense water into suspect source for approximately two to three minutes.
6. Pour dye from dispensing container into suspect source.
7. After dye has been dispensed, continue to dispense water for an additional five minutes.
8. Shut off water dispenser and observe downstream manhole for dye. Average time for dye travel has been 10 or 12 minutes.
9. Shut down trailer and store equipment according to manual procedures.
10. Record results and building data on appropriate form.